

# 314 BLANK PISTOL MODEL BP6000

## LOADING, SHOOTING & CARE INSTRUCTIONS

### WARNING

This blank pistol is chambered to fire only crimped 6mm caliber blank cartridges. This pistol is not to be used with any loaded ammunition containing any type of projectile nor with any powder activated fastening devices. Damage to mechanism caused by shooting without blank cartridge in the chambers will not be covered under warranty.

### TO LOAD

On left side of blank gun, pull the ejector rod assembly (5) out and pull the cylinder down and out from left side. Insert blank cartridges into chambers. Close securely by pushing the cylinder up and pulling out on the ejector rod.

### TO SHOOT

This pistol will fire in double or single action or single action. To fire the pistol in single action, pull hammer back to lock in down position. When ready to fire, pull trigger. To fire in double action, simply pull trigger with hammer in the "at-rest" or forward position. (Note: The double action trigger will have a heavier trigger pull than single action.)

### TO REMOVE CARTRIDGES

Pull out the ejector rod assembly and lower the cylinder out of the frame. Push on the ejector rod to expose the cartridges and pull out.

### CARE OF GUN


For dependable service, the gun must be cleaned and oiled periodically and always after each use. Remove powder and dust traces from gun and cylinder chambers and place a drop of oil on all moveable parts. Apply the same oil to a soft cloth and wipe outside of gun for protection against rust.

### WARRANTY

Thirty (30) day limited warranty. You will need to retain an original purchase receipt to validate your warranty. This warranty shall remain in force unless any of the following are determined by the Traditions™ Customer Service Department: Normal wear from regular and intended use, Failure to comply with the instructions listed here in the owner's manual, Modification of internal parts as they were shipped from the factory, A lack of proper maintenance and thorough cleaning is evident such as rust, customer abuse.

### PARTS LIST

1. Frame
2. Hammer
3. Trigger
4. Swing-out lever
5. Ejector rod assembly
6. Sear
7. Firing pin assembly
8. Cylinder
9. Hammer spring
10. Trigger spring
11. Sear spring
12. Grips



### WARNING

- ALWAYS WEAR SAFETY GLASSES AND HEARING PROTECTION
- HANDLE THIS BLANK REVOLVER AS YOU WOULD ANY FIREARM
- KEEP OUT OF REACH OF CHILDREN
- NEVER AIM AT A PERSON OR ANIMAL

### WARNING

Discharging firearms in poorly ventilated areas, cleaning firearms, or handling ammunition may result in exposure to lead and other substances known to the state of California to cause birth defects, reproductive harm, and other serious physical injury. Have adequate ventilation at all times. Wash hands thoroughly after exposure.

AKH 02/20 -  
6000I